


FIREBOX TOP ASSEMBLY



ITEMS MAY NOT APPEAR EXACTLY AS ILLUSTRATED

REF. NO.	PART NUMBER	DESCRIPTION
1	W010-2623	DOOR LATCHES (X2)
2	W705-0274	FIREBOX TOP
3	N402-0001	HIGH TEMP LIGHT ASSEMBLY
4	W290-0080	COVER PLATE GASKET

REF. NO.	PART NUMBER	DESCRIPTION
5	W300-0067	CERAMIC GLASS
6	W500-0288	LENS COVER PLATE